INSTALLATION AND SAFETY INSTRUCTIONS

FOR YOUR SAFETY

WARNING: BE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF; EITHER THE FUSE IS REMOVED OR THE CIRCUIT BREAKER IS SHUT OFF. GENERAL You don't need special tools to install this fixture. Be sure to follow the steps in the order given. Under no circumstances should a fixture be hung on house electrical wires, nor should a swag type fixture be installed on a ceiling which contains a radiant type heating system. Read instructions carefully. If you are unclear as to how to proceed, consult a qualified electrician. NOTE: Proper wiring is essential for the safe operation of this fixture.

GENERAL

You don't need special tools to install this fixture. Be sure to follow the steps in the order given. Under no circumstances should a fixture be hung on house electrical wires, nor should a swag type fixture be installed on a ceiling, which contains a radiant type heating system. Read instructions carefully. If you are unclear as to how to proceed, consult a qualified electrician.

NOTE: Proper wiring is essential for the safe operation of this fixture.

FIXTURE ASSEMBLY

Carefully removed the fixture from the carton and check that all parts are included as shown in figure. Be careful not to misplace any of the screws or parts which are needed to install this fixture.

INSTALLATION

IMPORTANT: Do not attach fixture directly to outlet box. **STEP1**: Secure universal mounting plate(L) on to outlet box with box screw(E).

Proceed to connect wires:

GROUNDING INSTRUCTIONS

STEP 1: Insert the green grounding screw into the hole with two raised dimples on the circular strap. Wrap the ground wire from the fixture (if supplied) around the green grounding screw, then connect it to ground wire from the outlet box (if not fixed on the outlet box) using a wire connector (not supplied). If ground wire from the fixture is not supplied, wrap the ground wire (if not fixed on the outlet box) from the outlet box around the green grounding

GROUP A: Connect to Black	GROUP B: Connect to White
House Wire	House Wire
BLACK	WHITE
*PARALLEL WIRE (round &	*PARALLEL WIRE (square &
smooth)	ridged)
WHITE OR GREY WITH	WHITE OR GREY
TRACER	WITHOUT TRACER
BROWNGOLDOR	BROWN, GOLD OR BLACK
BLACK WITHOUT TRACER	WITH TRACER
1.12.1.1	

screw and tighten it.

NEVER CONNECT GROUND WIRE TO BLACK OR WHITE POWER SUPPLY WIRES.

FINAL ASSEMBLY

Step 1: Fasten the mounting frame (L) to ceiling. Be sure that the frame is mounted securely to the building structure using long thick woodscrews (Not included, #10 or greater recommended). Woodscrews should be long enough to be in the wood structure at least 1.5" (not including frame, drywall/plaster, or wall cladding). When needed refer to page 2 for extra fastening/safety cable fastening instructions when applicable.

Step 2: Feed the lamp cord (C) through the coupling (H). Once fixture is at the desired height, hold it in place by tightening the set screw (G). Put the figure 8 buckle on the wire and snug it up to the fitting where the wire comes through the ceiling plate. Repeat for each pendant being attached to the canopy (I)

Step 3: Add a section of bridge wire for every 4 lamp cords (C). This is done by taking a loose piece of wire 1'-2' in length. Attach the wires from the 4 lamp cords (C) to one end of the wire (white to white, black to black, ground to ground).

Step 4: Group the remaining cords (C) and lamp wire together and attach them to the main power source from the junction box with wire connectors. Once again, white to white and black to black, ground to ground.

Step 5: Tuck excess wire inside of the junction box. Raise the canopy (I) to the mounting frame (L). Be sure that no loose wires are being pinched. Fasten the canopy (I) in place with screws (J) **Step 6**: Install the bulb (D) (Not included) into the socket cup (B) **Step 7**: Install the glass shade (A) into the socket cup (B) by placing it inside of the socket cup (B) and turning it.

CLEANING

To clean wipe fixture with a soft cloth. Clean glass with a mild soap. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

ORDERING PARTS

Keep this sheet for future reference, and in case you need to order replacement parts. All parts for this fixture can be ordered from place of purchase. Be sure to use exact wording from illustration when ordering parts.

Line art shown may not exactly match the fixture enclosed. However, the installations do apply to this fixture. ITEM NO: 740P-7L

